



TylerOptix

www.tyleroptix.co.za

Bifocal Lens Changing Instructions

Model: T096 Black-Yellow

These frames are made from a tough flexible material so can take the necessary force needed for this installation.

Step 1: Unclipping the lens

Hold the side of the temple hinge side firmly and at the same time gently twist the bridge nose part of the frame down away from the lens until it just clicks out on the corner.



Step 2: Removing the lens

Firmly holding the bridge nose part of the frame, pull the lens out of the frame.



Step 3: Installing the new lens

Adding a little water onto the lens will help lubricate and ease the rest the installation.
Fit the lens into the corner groove and slot of the frame.



Step 4: Installing the new lens

Squeeze the frame and lens together.



Step 5: Installing the new lens

When the lens clips into frame and slot the installation is complete.

